

Contact Prowatercraft Racing
if you have any issues or
questions
(928) 680-6660



Installation Instructions Generic Mat Install

ProwatercraftRacing.com



QR Code takes
you directly to the
Install Video.

**We highly recommend
that you watch the
Install Video before
starting this install.**



READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Remove old mats. Once the mats are removed make sure the bottom and sides are smooth. Sand if necessary.
- 2 Apply 2 coats of glue to one of the side mats. Let glue dry until its tacky but does not stick to your fingers when touched.
- 3 Apply 2 coats of glue to the respective side of your ski.
Place mat in place - always align the top of the mat first and press into place. Fig. 1 Continue to press the mat into place working from the top - down. Stretch the mat to wrap around the back of the ski and press into place. Fig. 2 Make sure there are no bubbles or wrinkles in the mat. Once the mat is securely in place trim excess mat at the bottom.
- 4
- 5 Use super glue to secure the edges of the mat to the ski.
- 6 Follow steps 2, 3, 4 & 5 for the other side of the ski.
- 7 Follow steps 2, 3, 4 & 5 for the front mat.



Fig. 1



Fig. 2

- 8 Next you will install the under mat. Follow the process as in steps 2, 3, 4 & 5. For the under mat start at the front and work your way to the back.
- 9 If you are installing the front hump and/or a rear kick tray. You will at this time place the front hump and tray in place and trace their outline so you can use a razor to cut out the under mat, Pull the under mat out
- 10 Apply 2 coats of glue to the front hump/rear tray and to the cut out are where they will go on the tray floor. Allow glue to dry until tacky but not sticky and press into place.
- 11 Apply 2 coats of glue to the under mat and the bottom mat. When the glue is ready apply the mat to the ski, starting with the front upper corners and then stretching the bottom mat into place over the rear tray and down the back and up and under. Fig. 4 Again use super glue to secure the edges of the mat to the ski.
- 12 Final step is to take a rubber mallet and tap the entire mat kit into place. Using the rubber mallet ensures a firm fit with no bubbles or wrinkles.



Fig. 3



Fig. 4