

Contact us if you have any issues or questions

[Sales@ProWatercraftRacing.com](mailto:Sales@ProWatercraftRacing.com) or  
[928-255-0230](tel:928-255-0230)



Installation Instructions  
Performance Mid Sponson

**PW-SP-225-HFC**



QR Code takes  
you directly to the  
Install Video.

***We highly recommend  
that you watch the  
Install Video before  
starting this install.***



Supplied with Kit:

- 10 - Button head bolts
- 10 - Washers
- 2 - Mounting Plates
- 1 - Sponson Set
- 1 - Bag of Loctite

**READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION**

- 1 Check your ski's measurement from rear and make a mark. (Fig 1)
- 2 Take and point the rounded-end of a mounting plate towards the front of your ski. Place the plate against the bond flange aligning the plate 2 inches forward from the mark you made. Mark inside 5 holes in the plate to drill. The front, back, and center hole of the plate are mandatory. (Fig 2)
- 3 Drill out the marked areas with a 1/4" drill bit. (Fig 3)
- 4 Align your mid sponson behind the bond flange with the backing plate. The rounded-end of the mounting plate points towards the front of the ski. The side with the rounded-end faces the hull.
- 5 Take your supplied bolts with washers and push through the bond flange, sponson, and thread into the mounting plate. Make sure to use Loctite when installing. (Fig 4 & 5)  
*Be careful not to cross thread the mounting plate. The bolts should thread in easily.*
- 6 Repeat these steps for the other side. Double check the tightness of each bolt after your first few rides.

**MEASUREMENTS FROM REAR**

SXR 800 --- 13 1/2" from back of hull

Round SJ --- 12" from corner bumper

