

The installation video is not available at
this time.



Supplied with Kit:

- 1 - Exhaust Insert
- 2 - Sponsons
- 14 - Screws
- 1 Tube of Silicone

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

Steps for installing the exhaust insert:

- 1 Sand the bottom and back areas of the exhaust insert to allow the silicone to stick. Fig. 1
- 2 Apply silicone to the sanded areas of the exhaust insert and slide into stock exhaust outlet. Fig. 2
- 3 Apply silicone to the inner hole and outer edge of the exhaust-cut sponson. Place overtop the exhaust outlet. There is only one placement option. Fig. 3
- 4 Screw the sponson into place and wipe off all excess silicone. Wipe away the excess silicone from inside the exhaust outlet and around the exhaust insert. You do not want any leaks later on. Fig. 4

Note: Fitment will depend on your ski's age and modifications. Adjustments may need to be made to the exhaust side to fit properly.

