

Contact us if you have any issues or questions

Sales@ProWatercraftRacing.com or
[928-255-0230](tel:928-255-0230)



Installation Instructions
HFC EXTENDED JET PUMP NOZZLE

PW-01-800

Our installation video will be available soon.



Supplied with Kit:
HFC Steering
Nozzle

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Remove the 2 pivot bolts attaching the nozzle to the pump with a 4mm allen key. FIG. 1
- 2 Remove the steering cable ball end from the nozzle with a 10mm wrench. FIG. 2
- 3 Install the steering cable ball end and washer onto our HFC Steering Nozzle. HFC material is threaded. We highly recommend the use of Loctite and 2 LBS torque is the max.
- 4 Place the HFC Steering Nozzle onto the pump nozzle. The part number should be facing the ride plate when finished.
- 5 Install the 2 pivot bolts from Step 1 using Loctite to the pump to attach our HFC Nozzle.
- 6 Double check your work before using.



FIG. 1

Please leave our products a review! ★★★★★
Send us an email with your review and receive a discount on your next order of PWR products.



FIG. 2