

Contact us if you have any issues or questions

Sales@ProWatercraftRacing.com or
[928-255-0230](tel:928-255-0230)



Installation Instructions
KAWASAKI SXR 1500
REAR SPONSONS

PW-01F-210



QR Code takes
you directly to the
Install Video.

Watch video for more details.



Tools Needed:
5mm Allen Tool
Loctite

Parts Included:
x1 set of Rear
Sponsons

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Remove the OEM sponsons with the 5mm allen tool.

NOTE: Removing the OEM hardware can be difficult because of OEM Loctite. Sometimes the washers attached to the collars can break off. If they break off, you can still use them.

- 2 Install the PWR Rear Sponsons using the OEM bolts and collars. Loctite is recommended when installing.
- 3 After your first ride, look over the sponsons and make sure the mounting and hardware is solid. Check the tightness of the bolts periodically. Retighten if necessary.

NOTE: There may be a gap between the sponson and hull, this is normal. Like the OEM sponsons, we do not want the sponsons to rub against the hull.

