

Contact us if you have any issues or questions

Sales@ProWatercraftRacing.com or
[928-255-0230](tel:928-255-0230)



Installation Instructions SUPERJET HULL EXTENSIONS

PW-03-700-SJ1



QR Code takes you to the install video.

We highly recommend you watch the video before starting install.



Tools Needed:

Drill
11/64" drill bit
Gloves, Rags
Caulk gun, Silicone*

Parts Included:

x1 set of SJ Hull Extensions
x6 Screws
x5 Washers

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Check the fitment of the hull extension to your hull. The hull extension should be flush with the hull.
- 2 Drill through the holes in the extension into the hull using the 11/64" drill bit. *Fig 1*
- 3 Brush away any debris and clean the area where the hull extensions will mount to.
- 4 If you do not have a flat rear exhaust, stick the provided washers into the exhaust flange space. *Fig 2*
- 5 Apply silicone to the hull extension and the holes in the back of the hull. *Fig 3*
- 6 Screw the extension back to the hull with the provided screws. Be careful of changes to the extension angle.
- 7 Clean off all excess silicone from the extension, hull, and exhaust. *Fig 4*
- 8 Repeat Steps 1-7 for the other side.
- 9 Allow for at least 12 hours for the silicone to cure before riding.



Fig 1



Fig 2



Fig 3



Fig 4

*Use of any other adhesive besides ProWatercraft's approved silicone will void the warranty. Use IS808 silicone adhesive.