



4 Stroke Yamaha SuperJet (PW-03SJ-810)

"Quick Steer" Bracket



1. Disconnect the steering cable from the steering nozzle.
2. Remove the OEM ball bolt using a 10mm wrench. We will reuse the nut and washer. **Fig 1**
3. Install the PW Quick Steer bracket to the steering nozzle using the supplied bolt and reusing the washer and nut from Step 2. **Fig 2**
4. Reconnect the steering cable to the steering nozzle.