



QR Code takes you to the install video.

We highly recommend you watch the video before starting install.



Tools Needed:
Drill, 1/8" drill bit
Straight Edge
Marker, Gloves, Rags
Caulk gun, Silicone*

Parts Included:
x1 set of Hull Extensions
x6 Screws

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1 Using the straight edge, line up the hull extension with the hull surface. Mark around the edges with the marker to save the position. **Fig 1**
- 2 Hold the hull extension into place and drill the holes through the extension. Be careful to not let the extension move out of position. **Fig 2**
- 3 Install one screw into the extension to hold it in place and then follow up with the remaining screws.
- 4 Repeat Steps 1 through 3 for the other side. **Important:** If you do not have a rear exhaust, stack 1/4" of washers on the backside of the left extension center screw to offset the gap. **Fig 3**
- 5 Remove both extensions and clean off the hull. Any dirt or debris will affect the silicone bond.
- 6 Apply silicone to the hull extensions and screw holes.
- 7 Screw the extensions back to the hull with the provided screws. Be careful of changes to the extension angle.
- 8 Wipe away excess silicone from the hull and extensions. Allow 24 hours for the silicone to dry. **Fig 4**



Fig 1



Fig 2



Fig 3



Fig 4

*Use of any other adhesive besides ProWatercraft's approved silicone will void the warranty. Use IS808 silicone adhesive.

*Skis without rear exhaust may need additional hardware. Our suggestion is stainless steel washers, 8mm ID and 24mm OD.