

The installation video is not available at  
this time.




Supplied with Kit:

- 2 - Sponsons
- 14 - Screws
- 1 Tube of Silicone

**READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION**

- 1 Position the sponsons evenly on both sides of the ski. Tape is very helpful to hold your sponsons in place until you get the placement you like.
- 2 Once the Sponson is in place - drill pilot holes for your screws using a 11/64th drill bit. Start from the front and work your way back. Fig. 2
- 3 After drilling your first pilot hole, insert one of the screws and tighten to help hold the Sponson in place.
- 4 Drill pilot holes for the rest of the Sponson, inserting the screws as you go along to hold the Sponson in place.
- 5 Run a strip of tape on the ski about 1/8th inch under the Sponson. Now run a strip of tape along the bottom of the Sponson.

- 6 Remove the Sponson from the ski.
- 7 Apply a bead of silicone around the inner edges of the Sponson.
- 8 Place Sponson in place and begin screwing it to the hull starting in the front and working your way back. Fig. 4
- 9 Once you have the Sponson attached to the hull, remove the tape from the Sponson and hull. Then use a towel or cloth to remove the silicone from the top of the Sponson. Ensure you remove all the silicone. Allow 24 hours to dry.



Note: The correct position for these sponsons is to have the sponson's flange parallel to the ski's bond flange and the leading edge of the sponsons is flush with the bottom of the hull.